

MPAGS Astrophysical Techniques 2023

Spectroscopy


Based on materials by M. Brogi and D. Steeghs


Marina Lafarga Magro (she/her)

marina.lafarga-magro@warwick.ac.uk




What is a spectrograph?






Collecting light



Slit: Mechanical aperture with 2 parallel jaws

- Width can be easily changed
- One spatial direction (along the slit) preserved
- Simultaneous spectrum of the sky
- Typical slit widths: 0.2 2.0"

Collecting light



Slit: Mechanical aperture with 2 parallel jaws

- Width can be easily changed
- One spatial direction (along the slit) preserved
- Simultaneous spectrum of the sky
- Typical slit widths: 0.2 2.0"


Fibre: Optical guide transmitting light through multiple reflections

- Very constant output (↑ stability)
- Instrument can be moved off-telescope (↑ stability)
- Additional fibre(s) for sky or calibration source
- Typical fibre diameters: 1.0 1.5" (match seeing)


Collecting light

Multiple slits/fibres can be combined to do **multi-object spectroscopy (MOS)**

Differential spectroscopy




Slit mask




Fibre MOS

• Earth's atmosphere refracts source light \Rightarrow Sky position of the source is λ -dependent!




- Earth's atmosphere refracts source light \Rightarrow Sky position of the source is λ -dependent!
 - Index of refraction depends on wavelength, temperature, pressure, water vapour
 - Dispersion happens along the horizon-zenith direction (airmass)
 - Dispersion larger for shorter wavelengths
 - Dispersion direction changes with time
- Affects acquisition and slit orientation
- Atmospheric Dispersion Compensator (ADC)

Case 1: Single object



- Earth's atmosphere refracts source light \Rightarrow Sky position of the source is λ -dependent!
 - Index of refraction depends on wavelength, temperature, pressure, water vapour
 - Dispersion happens along the horizon-zenith direction (airmass)
 - Dispersion larger for shorter wavelengths
 - Dispersion direction changes with time
- Affects acquisition and slit orientation
- Atmospheric Dispersion Compensator (ADC)


Case 1: Single object



Slit aligned at the parallactic angle


- Earth's atmosphere refracts source light \Rightarrow Sky position of the source is λ -dependent!
 - Index of refraction depends on wavelength, temperature, pressure, water vapour
 - Dispersion happens along the horizon-zenith direction (airmass)
 - Dispersion larger for shorter wavelengths
 - Dispersion direction changes with time
- Affects acquisition and slit orientation
- Atmospheric Dispersion Compensator (ADC)

Case 2: Multiple objects




- Earth's atmosphere refracts source light \Rightarrow Sky position of the source is λ -dependent!
 - Index of refraction depends on wavelength, temperature, pressure, water vapour
 - Dispersion happens along the horizon-zenith direction (airmass)
 - Dispersion larger for shorter wavelengths
 - Dispersion direction changes with time
- Affects acquisition and slit orientation
- Atmospheric Dispersion Compensator (ADC)

Case 2: Multiple objects



Wider slit to avoid losing light



Dispersing light: prisms, gratings, grisms

Incident light

Prism


- Uses variable index of refraction
 n(λ) to separate incident photons
 (≠ colours are dispersed at ≠ angles)
- Dispersion increases with path (i.e. larger prism ⇒ higher resolution)


.....

Dispersing light: prisms, gratings, grisms

Diffraction grating

- Uses diffraction + interference to separate incident photons
- Periodic carving in material with spacing ~ λ of light
- Diffraction orders at interference maxima
- Resolution \uparrow with line density
- Resolution \uparrow for higher orders (but intensity \downarrow)
- Most of the light goes to the first orders






Transmission grating (transmissive material)

Dispersing light: prisms, gratings, grisms


Grism

- Grating mounted on a prism interface
- Useful to correct for the path of diffracted light
 - Smaller instruments
 - Extreme angles (higher orders)



Dispersing light: blazed spectrographs


- Gratings can be *blazed* to concentrate light away from 0th order and towards higher orders
- Reflecting surfaces oriented at a specific blaze angle with respect to the surface of the grating
- Called echelette if used for low orders or echelle if used for high orders (large blaze angle, > 45°)
- Order overlap becomes a problem




Dispersing light: cross-dispersion


- The wavelength range of high orders strongly overlaps
- Want to measure λ_1 in order 99, but λ_2 in order 100 and λ_3 in order 101 contaminate your spectra
- Solutions:
 - Bandpass filters to selected desired λ range, but lose light
 - Cross-dispersion perpendicular to the initial spectral dispersion to separate the orders

Orders separated vertically for clarity





Dispersing light: cross-dispersion




Spectral resolution: separating spectral lines

What is the minimum distance between lines $(\Delta \lambda)$ to be considered spectrally resolved?

- Spectral resolution: $\Delta \lambda$
- Resolving power: $R = \lambda / \Delta \lambda$

Related to **Doppler shift**: $\Delta v \sim c/R$

E.g. R =100 000 \implies Resolve 3 km/s in velocity or 0.005 nm in wavelength at 500 nm




Spectral resolution

Resolution is driven by the **slit width/fibre size** (up to 1") or by the **seeing** (for wider slits/fibres)

Resolution increases with **density of lines in grating** & **order number**

How to achieve high resolution?



Spectral resolution


Resolution is driven by the **slit width/fibre size** (up to 1") or by the **seeing** (for wider slits/fibres)

Resolution increases with **density of lines in grating** & **order number**


How to achieve high resolution?

- ↓ slit size
- ↑ density of lines in grating
- ↑ order number (high angles)


Trade-off between resolution & amount of photons!




Spectral resolution



Let's have a look at some data




Dispersion direction




Spectral or dispersion direction = Wavelength


- Light is dispersed perpendicular to the slit \Rightarrow Spatial information perpendicular to the slit is lost and becomes the spectral direction
- Sources have a specific location on the slit \Rightarrow Spatial information along the slit is available, spectrum localised at specific spatial positions





Spectral or dispersion direction = Wavelength


• Sky enters the slit everywhere \Rightarrow Sky emission lines appear everywhere along the spatial direction















MPAGS Astrophysical Techinques | Spectroscopy

Extracting the spectrum


Calibrating the detector

- Bias & Dark frames are treated in the same way as for imaging
- Spectroscopic flats (with slit, light path as close as science observations)
 - Uniform illumination along slit & in the dispersion direction ⇒ Light source with a smooth and simple spectrum (e.g. tungsten lamp)
 - Correct by e.g. averaging along the spatial direction, fitting the spectrum, dividing out
 - Dome or twilight-sky flats for non-uniformity in spatial direction (do not help in spectral direction, with or without slit)
 - Creating a proper spectroscopic flat is complicated!
 - Sometimes flat-fielding can worsen the data




Sky background: Optical

- Background has contributions from many sources
 - Air glow: Strong, discrete emission lines (fluorescence of atmospheric OH, O, Na, & city lights Hg)
 - Zodiacal light
 - Sun/Moonlight
 - Auroare
 - Light pollution
 - Thermal emission from sky, telescope and buildings
 - Non-resolved astronomical background




Sky background: Infrared

- Thermal emission from the sky, ground and telescope dominates
- Observations become very challenging for.
 λ > 5 μm




Atmospheric transmission


- Atmospheric transmission strongly depends on λ
- Source spectrum will be imprinted by Earth's transmission spectrum
- At visible wavelengths Earth atmosphere almost transparent




Atmospheric transmission: Telluric spectrum




Atmospheric transmission: Telluric spectrum



Extracting long-slit spectra



Extracting long-slit spectra



Spectrum(λ) = $\sum_{y,aperture} [(source(y, \lambda) - sky(y, \lambda)) * weight(y, \lambda)]$

- Challenge: Spectral trail can be tilted with respect to the spectral direction
- Challenge: Sky lines can be tilted with respect to the spatial direction
- Optimal extraction: weight by a smoothed 2D profile (Horne 1986)

- Associate a wavelength to each of the pixels along the spectral direction
- Requires a **reference spectrum** with known wavelengths

Sky emission lines

- Simultaneous, observer reference frame
- Not accurate with very wide slits


Sky absorption lines

- Simultaneous, observer reference frame
- Few lines in optical, fine in near-infrared

Stellar spectral lines

• Simultaneous, stellar frame

Spatial direction



Science observation

Spectral direction

- Associate a wavelength to each of the pixels along the spectral direction
- Requires a **reference spectrum** with known wavelengths

Sky emission lines

- Simultaneous, observer reference frame
- Not accurate with very wide slits

Sky absorption lines

- Simultaneous, observer reference frame
- Few lines in optical, fine in near-infrared

Stellar spectral lines

• Simultaneous, stellar frame

Gas absorption cell in optical path

- Simultaneous, observer reference frame
- Reduces amount of photons from source
- Very accurate (m/s)

HARPS lodine cell



- Associate a wavelength to each of the pixels along the spectral direction
- Requires a **reference spectrum** with known wavelengths

Sky emission lines

- Simultaneous, observer reference frame
- Not accurate with very wide slits

Sky absorption lines

- Simultaneous, observer reference frame
- Few lines in optical, fine in near-infrared

Stellar spectral lines


• Simultaneous, stellar frame

Gas absorption cell in optical path

- Simultaneous, observer reference frame
- Reduces amount of photons from source
- Very accurate (m/s)

Emission line lamps (arcs): Ar, Th, He, Ne, Cu...

- Not always simultaneous, observer reference frame
- Stable source, very accurate (m/s)



Emission lamp observation (long-slit)

Wavelength calibration: from pixel to $\boldsymbol{\lambda}$

- Associate a wavelength to each of the pixels along the spectral direction
- Requires a **reference spectrum** with known wavelengths

Sky emission lines

- Simultaneous, observer reference frame
- Not accurate with very wide slits

Sky absorption lines

- Simultaneous, observer reference frame
- Few lines in optical, fine in near-infrared

Stellar spectral lines


• Simultaneous, stellar frame

Gas absorption cell in optical path

- Simultaneous, observer reference frame
- Reduces amount of photons from source
- Very accurate (m/s)

Emission line lamps (arcs): Ar, Th, He, Ne, Cu...

- Not always simultaneous, observer reference frame
- Stable source, very accurate (m/s)



Spectral direction

- Associate a wavelength to each of the pixels along the spectral direction
- Requires a **reference spectrum** with known wavelengths

Sky emission lines

- Simultaneous, observer reference frame
- Not accurate with very wide slits

Sky absorption lines

- Simultaneous, observer reference frame
- Few lines in optical, fine in near-infrared

Stellar spectral lines

• Simultaneous, stellar frame

Gas absorption cell in optical path


- Simultaneous, observer reference frame
- Reduces amount of photons from source
- Very accurate (m/s)

Emission line lamps (arcs): Ar, Th, He, Ne, Cu...

- Not always simultaneous, observer reference frame
- Stable source, very accurate

Fabry-Perot & Laser frequency comb

- Simultaneous, observer reference frame
- Very stable, very accurate



Wavelength calibration: from pixel to $\boldsymbol{\lambda}$

- Associate a wavelength to each of the pixels along the spectral direction
- Requires a **reference spectrum** with known wavelengths

Sky emission lines

- Simultaneous, observer reference frame
- Not accurate with very wide slits

Sky absorption lines

- Simultaneous, observer reference frame
- Few lines in optical, fine in near-infrared

Stellar spectral lines

• Simultaneous, stellar frame

Gas absorption cell in optical path

- Simultaneous, observer reference frame
- Reduces amount of photons from source
- Very accurate (m/s)

Emission line lamps (arcs): Ar, Th, He, Ne, Cu...

- Not always simultaneous, observer reference frame
- Stable source, very accurate


Fabry-Perot & Laser frequency comb

- Simultaneous, observer reference frame
- Very stable, very accurate

Instrument flexures, seeing/pointing variations, temperature and pressure changes... all influence the wavelength solution

Flux calibration: from counts to flux

- Convert the measured counts into fluxes
- Requires a reference spectrum with known fluxes as a function of λ (spectrophotometric standard star), usually a hot star
- Differential spectrophotometry
- Also useful for correcting telluric absorption (hot star spectrum is almost featureless)



Dos & don'ts when working with data

- Instrument manuals are the best resource to learn about spectrographs (also literature using the same instrument)
- Always visually inspect calibration and science frames for quality check (plot, plot, plot!)
- Instrument pipelines & software packages are extremely useful, but do not use them as black boxes (but do not reinvent the wheel either)
- **Tune** the reduction/analysis to your science
- Know your **noise** (read-out noise + Poisson noise + background noise + systematics) and S/N regime

Assignment

Long-slit spectroscopy with ACAM (Auxiliary-port CAMera) at the 4.2 m WHT (William Herschel Telescope) in La Palma, Canary Islands, Spain

- ACAM mounted at WHT Cassegrain focus → flexures during telescope pointing
- ACAM does photometry (variety of filters) and low-resolution spectroscopy (R < 900) between 350 and 940 nm




<u>https://www.ing.iac.es/Astronomy/instruments/acam/</u> <u>https://www.ing.iac.es/Astronomy/instruments/acam/spectroscopy.html</u> https://www.ing.iac.es/Astronomy/telescopes/wht/

Assignment








Assignment




Visualising ACAM spectra in DS9









Useful DS9 tools: Regions

	-				SAOImage ds	Get Information			
le bject alue ICS	science_spe GJ3470			[Shape Composite Region Instrument FOV Template	* * *	Circle Ellipse Box Polygon	
nysical X nage X rame 1 x file edit		Y Y frame	0 bir	° 1 Zoom	scale	Color Width Properties Font	* * * *	✓ Line Vector Projection Segment	help
grey	a	b	bb	he) <mark>i8</mark>	Centroid Move to Front Move to Back		Text Point	rainbow
			1450			Select All Select None Invert Selection	ЖA	Compass Annulus Elliptical Annulus	
						Delete Selected Regio Delete All Regions New Group Groups	ons	Box Annulus Panda Elliptical Panda Box Panda	
						List Regions Load Regions Save Regions			
			4 1999-14			Region Parameters			

Assignment checklist

- Have **DS9** and **Python** installed (code written in Python 3)
- **DS9** self-explanatory: just play around with the interface and try different options
- All the instructions and questions to answer are in the Jupyter notebook
- Make sure you have basic python libraries (**numpy** for manipulating arrays, **matplotlib** for plotting)

https://warwick.ac.uk/fac/sci/physics/mpags/modules/astro/at/

Admissions → Modules → Ast	artment of	Students +		le≁ News & Events≁ Inclusion Vacanci	Search Warwick es Physics A to Z Contact Us	Q				o the botto signment m			
Conveners and Kennedy, Joe I Module Code:	Lyman, Lauren Doy	ck): Pier-En		Wilson, Peter Wheatley, Paul Strøm, Gra ob Van den Eijnden, Kendall Ackley	nt								
Start: Monday Teams meeting where they can coordinator Pi as possible *an reported to th effort basis - le Troubleshootii Settings 2) Acc	in join live meeting ier-Emmanuel Tren nd* email course co e course coordinal ecturers are not ob	a noon-2pm ad and all re . If you have hblay <u>p.tren</u> ordinator to or who will liged to rep ave a Micro nd write do	registered but can not join blay@warwick.ac.uk. If you access live meetings. Any o endeavour to find a solution ace failed or faulty recordin soft account and want to us wn the email address under	nal students have be added to the Teams 1 the Teams group, please email course 1 haven't registered yet, please do so as sc connection problems should also be n. Session recordings will be made on a be ngs. se it, open the Teams application, go to 1) r your account. You will need to send us th	est-		Home wor The deadl valid atte • <u>Assi</u> ma	291 by rkussignme i e for all a pt on at le <u>iment 1</u> 2 : <u>al</u> 2, <u>Astro</u>	A1.2 ents (may be update assignments is one east four of the five questions related	ed up to day of the sess week after lecture. A p assignments.	ion). bass mark for 1 . Deadline: We	ta Mining MPAGS credit will be ed 8th Nov. Related ma @warwick.ac.uk,	
-		and locatio	n of the first lecture) :					Contraction of the second second		ecture on CCDs, photo nent sheet (email: Mari		ectroscopy. Note: lectu gro@warwick.ac.uk,	re slides are in th
Week Date 5 Mon 30 O	nday noon-2pr	A0.28	Session leaders Lauren Doyle / Tom Wilson Marina Lafarga Magro /	Topic Observational Astronomy (<u>Lecture slid</u> <u>Teams recording</u> 전) Optical/IR Astronomy - photometry &	les ⊵',		Samue Assign	el.Gill@war nment 3: qu	rwick.ac.uk)	ecture on interferome		aterials: slides, iPython	notebook. (emai

https://warwick.ac.uk/fac/sci/physics/mpags/ modules/astro/at/mpags_2023_optical_phot ometry_assignment/

